












Spare Parts Catalogue Passenger Car



PICTURE	SEITLEN	PART NO.	DESCRIPTION	APPLICATION
	68069662AB	68069662AB	SHOCK ABSORBER	CHRYSLER
	68072063AE & 68072063AF	68072063AE & 68072063AF	SHOCK ABSORBER	CHRYSLER
	68072062AE & 68072062AF	68072062AE & 68072062AF	SHOCK ABSORBER WITH SENSOR	CHRYSLER
	04670508AG	04670508AG	CONTROL ARM	CHRYSLER
	04670509AG	04670509AG	CONTROL ARM	CHRYSLER
	04782561AE	04782561AE	CONTROL ARM	CHRYSLER
	04782612AC	04782612AC	CONTROL ARM	CHRYSLER
	04782613AC	04782613AC	CONTROL ARM	CHRYSLER



PICTURE	SEITLEN	PART NO.	DESCRIPTION	APPLICATION
	04782665AB	04782665AB	CONTROL ARM	CHRYSLER
	04782666AB	04782666AB	CONTROL ARM	CHRYSLER
	68045330AC	68045330AC	CONTROL ARM	CHRYSLER
	68051638AB	68051638AB	CONTROL ARM	CHRYSLER
	68051639AB	68051639AB	CONTROL ARM	CHRYSLER
	68184782AB	68184782AB	CONTROL ARM	CHRYSLER
	68184784AA	68184784AA	CONTROL ARM	CHRYSLER
	05168389AB	05168389AB	CONTROL ARM LOWER	CHRYSLER